


Convec FloorLine

CHR

- (GB) Connections, CHR room thermostat
- (D) Anschluß, CHR Raumthermostat

- (DK) Tilslutninger, CHR rumthermostat
- (RUS) Подключение к комнатному термостату CHR




(GB) Connection diagram CHR

(D) Schaltschema CHR

(DK) Tilslutningsdiagram CHR

(RUS) Схема подключения к комнатному термостату CHR



Convec FloorLine


BMS - ETS - CTS

Connections, BMS system

Anschluß, ETS Anlage

Tilslutninger, CTS system

Подключение к системе BMS



Connection diagram BMS

Schalschema ETS

Tilslutningsdiagram CTS

Схема подключения к системе BMS

